



REPRESENTACIONES INDUSTRIALES C Y M SAC

- *Comercialización de Equipos y Accesorios NDT*
- *Comercialización de Productos para Seguridad Industrial*
- *Comercialización de Equipos y Productos a nivel Industrial*

Sistema de Filtración – SPLITTER



These compact, portable, cabinet-enclosed machines are perfect for shop or department use where daily waste volumes range from under a drum up to about 250 gallons. All three models—Splitter Jr., Splitter and Splitter XD—are fully automated, extremely quiet and energy-efficient. They are designed to run unattended and feature a number of patented control monitoring devices to ensure that the machine will shut itself off before any type of damaging condition can occur.

Controls include:

- Microprocessor with 3-Position Timer
- PSI (pressure) Gauge
- High Temperature Warning Light
- High Temperature Limit
- Low Pressure Cutout
- Thermal Motor Overload Protection
- Ground Fault Circuit Interceptor (GFCI) Plug

Ultra-Filtration membranes (one in Splitter Jr. and two in Splitter and Splitter XD) are available in various pore sizes from micro- to nano-filtration.

Specifications	Splitter Jr.	Splitter	Splitter XD
Nominal Capacity, gal	50	125	250
Weight (wet) lbs	135	140	150
Depth	17"	17"	17"
Width	22"	22"	22"
Height	28"	28"	39"