



REPRESENTACIONES INDUSTRIALES C Y M SAC

- *Venta de Equipos NDT*
- *Venta de Accesorios NDT*
- *Venta de Productos para Seguridad Industrial*

Densitómetro para películas- SM 14 Densitometer



The rugged durability, minimal drift and no warm up time provide fast dependable readings. With the film on your viewer, place the SM-14's "EASY READ" probe over the area to be read then push the read button.. The large digital meter instantly displays the reading. It will return to the energy saving "stand-by" mode automatically.

- Measuring Range 0.00 to 4.00 D
- Accuracy ± 0.02 D / Repeatability ± 0.01 D
- No Warm-up Time
- Portable Power Source (9-volt Alkaline Battery Included)
- Weight 5.9 oz. / 167.2 grams
- Dimensions Height: 2.5 Inches (6.35 cm) / Width: 1.5 Inches (3.81 cm) Length: 4.75 Inches / (12.06 cm)