



## REPRESENTACIONES INDUSTRIALES C Y M SAC

- *Venta de Equipos NDT*
- *Venta de Accesorios NDT*
- *Venta de Productos para Seguridad Industrial*

### Negatoscopio View Lite 0417 LG con Luz Verde - LED (220 V)



#### Description

View-Lite 0417LG LED high Intensity Industrial X-Ray Film Viewer is developed according to the ASME 2007 Boiler@Pressure vessel Code requirement. Min. film density > 4.0 D.

View-Lite 0417LG viewer use rugged aluminum frame and industrial plastic molded side cover with adjustable handle.

It's complete portable design for field work application.

View-Lite 0417LG viewer use high power LED with adjustable dimmer light control and foot switch on/off control. High power circulating cooling fan can cool down LED temperature.

All modules design with high quality parts, easy assemble and easy repair



## REPRESENTACIONES INDUSTRIALES C Y M SAC

- *Venta de Equipos NDT*
  - *Venta de Accesorios NDT*
  - *Venta de Productos para Seguridad Industrial*
- 

### Specification

Max. light Intensity: 170000 lux ( 56,000 cd/m<sup>2</sup> ) 565 um Green Light

View film density: 4.0 D

Viewer window light uniform: above 0.95 full view window

Adjustable dimmer control: from 25-100% continuous

Handle: adjustable with different angle

Surface temperature: approx. 40 degree C after 30 min. full light operation

Viewer window size: 300 x 75 cm

Power requirement: 110 VAC or 220 VAC

Dimension: 570x170x 80 mm ( LxWxT )

Total Weight: 3.7 Kgs

### Standard Package

- 1 x main unit
- 1 x foot switch
- 1 x carrying case
- 1 x operating manual
- 1 x warranty card